



Billet weighing system is customized to fit in to existing roller table. The system is capable to accurately record the weight of moving billet with suitable stopper arrangement and lifting for high temp hot billets. Also the system can be integrated with PLC to record the billet weight in synchronization with PLC. We also provide the customized software application to monitor the billet production process. Fully integrated billet weighing system used to measure the hot and cold billet in static and dynamic mode.

Billet Weighing System

BWS Series

Model	BWS Series
Design	Weigh Frame Suitable for Roller Table
Capacity	Up to 100 ton
Resolution	1/2/5/10-100 kg/User Selectable
Zero / Tare	Auto Zero /Auto
Controller	SAM 3 X / ARM
Memory	In built with RTC
Communication	RS 232 / RS 485/ Profibus / Modbus/RF
Input/Output	Digital / Analog 4-20mA
Software	Dot Net / MS Access / SQL